

Easy Installation Of A 50mL Dual Syringe Cartridge + Manual Dispense Gun

01 Prep + Load 50mL Dual Cartridge + Manual Dispense Gun

Select your 50ml cartridge of adhesive and match its mix ratio to the corresponding plunger. Insert plunger into the dispense gun, then insert the cartridge and snap into place. Give the end of the plunger a little bump to fully secure.

02 Purge Material + Attach Static Mixer

Remove cartridge cap and dispense material to make sure the plungers are seated properly. Check that the material is coming out of both sides of the cartridge. Attach the static mixer tip with a simple quarter turn.

03 Prep Test Section + Begin Application

Begin to pump the material through the static mixer tip. Dispense a test bead the length of the mixer to know there is good material coming out. Once the proper mix is achieved, begin your application as planned.

Don't Forget...

Mix the extra test portion so it will cure. Properly dispose of the cured adhesives.



**RUDOLPH
BROS. & CO**



1-800-375-0605
Option 8 for 24/7 Service



www.rudolphbros.com
rbcsupport@rudbro.com