

# **Technical Process Bulletin**

Technical Process Bulletin No. 235579 This Revision: 01/08/2004

# ALODINE® 1200S-RTU Spray

# 1. Introduction:

ALODINE 1200S-RTU is a ready to use liquid product which produces a chromate conversion coating on aluminum and its alloys. The coating produced provides excellent protection for unpainted aluminum and bonds paint well.

# 2. Operating Summary:

Chemical:	Bath Preparation per 100 Gallons:
ALODINE 1200S-RTU	Used as received without dilution
Operation and Control:	
Time:	15 to 30 seconds
Temperature:	70° to 100° Fahrenheit

## 3. The Process:

The complete process normally consists of the following steps:

- A. Cleaning
- B. Rinsing
- C. Treating with the ALODINE 1200S-RTU processing solution
- D. Rinsing
- E. Drying

The work, after drying, is ready for use either painted or unpainted.

4. Material:

ALODINE 1200S-RTU

### 5. Equipment:

The work is processed in conventional spray processing equipment. The equipment for the ALODINE coating chemical should be constructed of stainless steel (Type 316 preferred for weldability) or other suitable acid-resistant material, but no lead or glass.

All heated tanks should be equipped with steam plate coils and side heating (preferred for a more even temperature distribution) or other heat sources capable of heating the bath to the specified temperature.

Acid-resistant crates, baskets, tumbling barrels, or conveyors, etc., should be provided to carry the work through the various stages.

NOTE: Detailed equipment specifications for a particular processing line should be obtained from your technical representative.

## 6. Surface Preparation:

#### Cleaning:

All metal to be treated with the processing solution must be free from grease, oil and other foreign material before treatment. A complete line of cleaners is available. Our representative will recommend the proper cleaner for your processing needs.

#### Water Rinsing:

After cleaning, the metal must be thoroughly rinsed with water. The rinse should be overflowed continuously at a rate which will keep it clean and free from scum and contamination.

## 7. Treating with the ALODINE 1200S-RTU Processing Solution:

Each alloy reacts with the ALODINE 1200S-RTU conversion chemical bath to produce a coating that is characteristic of that alloy. For the treating time selected, the bath should produce a light iridescent gold to tan coating on aluminum.

The data contained herein are normal for most installations; however, your technical representative may suggest a deviation from this data if indicated by production conditions.

If the ALODINE coating is powdery, the cause may be one or more of the following:

- 1. The work has been improperly cleaned and/or rinsed.
- 2. The coating time is too long.
- 3. The bath temperature is too high.

If the ALODINE coating is too light, the cause may be one or more of the following:

- 1. The treating time is too short.
- 2. The temperature of the bath is below the specified range.

#### Operation:

Time: 15 to 30 seconds. Temperature: 70° to 100° Fahrenheit.

## 8. After Treatment:

## Rinsing and Drying:

Unreacted coating chemical should be removed by one of the following methods:

- 1. Flush the work thoroughly with clean water followed by (a) air drying; (b) blowing dry with compressed air; (c) warm or hot air drying; or (d) wiping dry with clean cloths.
- 2. Wipe with water-damp cloths followed by wiping dry with clean cloths.

Any seams, joints and crevices should be blown dry with clean, dry, compressed air and the moisture splatters wiped dry with clean rags.

# 9. Storage Requirements:

This chemical should be stored indoors away from alkaline and organic materials. Do not allow ALODINE 1200S-RTU to freeze. Do not store with chlorine containing materials.

## 10. Waste Disposal Information:

Applicable regulations covering disposal and discharge of chemical should be consulted and followed.

Disposal information is given on the Material Safety Data Sheet for this product.

The solution is acidic and contains hexavalent chromium and fluoride. Waste treatment and neutralization may be required prior to discharge.

## 11. Precaution:

Consult the appropriate Material Safety Data Sheets for safety and handling guidelines for the products and reagents listed in this bulletin.

\_ \* \* \* \* \* \_

®Registered trademark of Henkel Corporation.

Henkel Technologies 32100 Stephenson Highway Madison Heights, MI 48071 Telephone: 248-583-9300 Fax: 248-583-2976 "The information presented herein is our interpretation of certain test results and field experience to date. This information is not to be taken as warranty or representation for which we assume legal responsibility, nor as permission or recommendation to practice any patented invention without a license. It is offered solely for your consideration, investigation and verification." © Henkel Corporation.

Distributed by: Rudolph Bros. & Co. PO Box 425, Canal Winchester, OH 43110 Phone: 614-833-0707 Fax: 800-600-9508 e-mail: <u>rbcsupport@rudbro.com</u> www.rudbro.com